Care and Cleaning Instructions for 3D Laminate Components

Cleaning

Always use a clean microfiber cloth or non-abrasive sponge.

• Wipe with a damp cloth or sponge with mild dish soap and water. For tougher spots, wipe with a damp cloth or sponge using a mild degreaser such as Simple Green® (with a 50/50 mix of water), standard Fantastik® or standard Formula 409®.

Cleaners to Avoid

- Any abrasive cleaner
- Solvent based cleaners and harsh chemicals
- Any cleaner in combination with a brush
- Cleaners containing ammonia
- Baking soda

If any chemical is spilled on a 3D Laminate surface, wipe it up immediately. Then wash the surface with soapy water and rinse several times.

Care

Special care must be taken when using toasters, grills, coffee makers and any counter top appliance that generates heat or steam to ensure that doors are not subjected to excessive temperatures.

Special care must also be taken when using the self cleaning option on a standard oven. It is recommended that a heat shield be installed to deflect and shield excessive radiant and convective heat.